

Rockchip Driver Assistant

- Support Rockusb Driver & Rockchip Adb Driver (un)installation.
- Support Windows XP, Winows 7 32/64bits, Windows 8 32/64bits .

Directories

- Driver: Rockusb driver directory
- ADBDriver: Rockchip ADBdriver directory

Notice

1. Please uninstall (卸载) first before installing (安装), in order to use the most recent drivers for all rockchip devices.
2. In Windows XP, after installing driver, it'll prompt finding new device the first time you plug in any Rockchip ADB device. In this case, please select "auto install", and driver installation will be completed successfully.

瑞芯微驱动安装助手

- 支持 Rockusb 驱动和 Rockchip Adb 驱动预安装和卸载
- 支持 xp,win7_32,win7_64,win8_32,win8_64 操作系统

目录说明

- 工具目录\Driver: Rockusb 驱动目录
- 工具目录\ADBDriver: Rockchip ADB 驱动目录

注意事项

为了所有设备都使用更新的驱动，请先“卸载”再进行“安装”
xp 系统当通过工具安装驱动完成,连接 Rockchip ADB 设备时还会提示你发现新设备，安装驱动时选择"自动安装",即可成功完成驱动安装。